


# Washing machine usage

The washing machine is located in the plastic shed, outside the back door.



## Quick steps

1. Turn on
2. Turn Options Dial to 30 degrees
3. Press Start button

To Open main door, pull the handle on the right hand side